

www.cornelius.com

ILLUSTRATED PARTS LIST

XTREME ICE MAKER (522 AND 530 SERIES)

MODEL NO.

631805001

631805002

631805003

631805004

631805005

631805006

631805007


631805020

631805021

631805030

631805031

631805032



Distributed By:

Commercial Refrigeration Service, Inc.

WWW.CorneliusParts.COM

WWW.IceCubes.NET

(866) 423-6253

(623) 869-8881



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 1. GENERAL ASSEMBLY (AIR CONDENSER SHOWN)

Item No.	Part No.	Name
1	161168006	Screw TC 8-32 HX 12
2	164510000	Nut Grommet
3	166194001	Grille Plstc Blk
4	631500117	Kit Svc Front Panel Asy 530 Series (See Figure 13)
	631500118	Kit Svc Front Panel Asy 522 Series (See Figure 13)

Item No.	Part No.	Name
5	630201041	Cover Elec Box
6	318308000	Screw TR 10-32 PAPH 32
7	630201049	Cover Top (530 Models)
	630201053	Cover Top (522 Models)
8	630900867	Panel Splash



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 2. TRIM ASSEMBLY (AIR CONDENSER SHOWN)

Item No.	Part No.	Name
1	07578	Screw TC 8-32 TRPH 12
2	630201037	Brace Elec Box (522 Model)
	630201033	Brace Elec Box (530 Model)
3		Electrical Box Ass'y (See Figure 10)
4	165384000	Screw SM 8 TA HX 16
5	630201034	Panel Side RH 120V 60HZ
	630201193	Panel Side RH 230V 50/60HZ
6	630900893	Washer SL .340 I.D.

Item No.	Part No.	Name
7	630900808	Swt Rocker On/Off 120V 60HZ
	630900924	Swt Rocker On/Off 230V 50/60HZ
8	630900798	Switch Proximity
9	630900828	Cover Evap Medium
10	630900870	Fitg Placeholder
11	630900908	Orifice Flow Reducer
12	631500120	Kit Svc Water Distributor Asy (See Figure 11)



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 3. REFRIGERATION ASSEMBLY

Item No.	Part No.	Name
1	161862005	Sensor Tmp (Air Condenser)
2	161426001	Clamp Gear No. 12
3	630000789	Valve and Brkt Svc (522 Series)
	630000786	Valve and Brkt Svc (530 Series)
4	166184002	Dryer Filter
5	165384000	Screw SM 8 TA HX 16 (Remote)

Item No.	Part No.	Name
6	161921007	Valve Expan
7	165629006	Valve Hot Gas and Snd 120V 60HZ
	165629013	Valve Hot Gas and Snd 230V 50/60HZ
8	165677008	Switch Prs Asy
9	165629014	Solenoid Liq



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 4. BUILD ASSEMBLY (AIR CONDENSER)

Item No.	Part No.	Name
1	630201054	Wrap Cab (522 Series)
	630201042	Wrap Cab (530 Series)
2	165384000	Screw SM 8 TA HX 16
3	650057	Tube Poly .265 I.D. (Sold by the Foot)
4	630200935	Flange Bulkhead Fitg
5	630900783	Fitg Blkhd 3/8 Comp x 3/8 MF
6	630201072	Flange Bulkhead Fitg
7		Condenser Ass'y (See Figure 9)
8	630900868	Sensor Pressure Pickup
9		Water Pump Ass'y (See Figure 12)
10	630900895	Nut Hex 8-32
11	630900869	Pan Water Wrap
12	631500053	Kit Comp 120V 60HZ
	630900739	Comp 230V 50HZ
	630900738	Comp 230V 60HZ

Item No.	Part No.	Name
13	164083005	Nut Hex 5/16-18
14	164154001	Washer Ft .375 I.D.
15	630900745	Sleeve Grommet Comp
16	630900744	Grommet Mount Comp
17	630900786	Valve Solenoid Water 120V 60HZ
	630900791	Valve Solenoid Water 230V 50/60HZ
18	630201036	Brace Bulkhead
19	638006070	Tube .375 I.D.
20		Bulkhead Ass'y (See Figure 7)
21	164126000	Screw SM 8 TA TRPH 16
22	165637008	Valve Dump 120V 60HZ
	165637009	Valve Dump 230V 50/60HZ
23	630201086	Brkt Wtr Pan
24	630000788	Base Chassis (522 Series)
	630000759	Base Chassis (530 Series)
25	630201126	Brkt Wtr Pan Cap



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 5. BUILD ASSEMBLY (REMOTE)

Item No.	Part No.	Name
1	630201054	Wrap Cab (522 Series)
	630201042	Wrap Cab (530 Series)
2	165384000	Screw 8 TA HX 16
3	650057	Tube Poly .265 I.D. (Sold by the Foot)
4	630200935	Flange Blkhd Fitg
5	630900783	Fitg Blkhd 3/8 Comp x 3/8 MF
6	630201072	Flange, Bulkhead Fitg
7	630201052	Panel Back
8	630900868	Sensoe Pressure Pickup
9		Water Pump Ass'y (See Figure 12)
10	630900895	Nut Hex 8-32
11	630900869	Pan Water Wrap
12	631500053	Kit Comp 120V 60HZ
	630900739	Comp 230V 50HZ
	630900738	Comp 230V 60HZ
13	164083005	Nut Hex 5/16-18

Item No.	Part No.	Name
14	164154001	Washer Ft .375 I.D.
15	630900745	Sleeve Grommet Comp
16	630900744	Grommet Mount Comp
17	630900786	Valve Solenoid Water
18	630201036	Brace Bulkhead
19	630900225	Receiver
20		Bulkhead Ass'y (See Figure 7)
21	164126000	Screw SM 8 TA TRPH 16
22	165637008	Valve Dump
23	630201086	Brkt Wtr Pan
24	630000788	Base Chassis (522 Series)
	630000759	Base Chassis (530 Series)
25	164820914	Brkt Rec Btm
26	01022	Washer Lk .380 I.D.
27	09652	Nut Hex 3/8-16
28	630201126	Brkt Wtr Pan Cap



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 6. BUILD ASSEMBLY (WATER COOLED)

Item No.	Part No.	Name
1	630201054	Wrap Cab (522 Series)
	630201042	Wrap Cab (530 Series)
2	165384000	Screw SM 8 TA HX 16
3	650057	Tube Poly .265 I.D. (Sold by the Foot)
4	630200935	Flange Bulkhead Fitg
5	630900783	Fitg Blkhd 3/8 Comp x 3/8 MF
6	630201072	Flange Bulkhead Fitg
7	630201051	Panel Back
8	630900868	Sensor Pressure Pickup
9		Water Pump Ass'y (See Figure 12)
10	630900895	Nut Hex 8-32
11	630900869	Pan Water Wrap
12	631500053	Kit Comp 120V 60HZ
	630900739	Comp 230V 50HZ
	630900738	Comp 230V 60HZ
13	164083005	Nut Hex 5/16-18
14	164154001	Washer Ft .375 I.D.
15	630900745	Sleeve Grommet Comp

Item No.	Part No.	Name
16	630900744	Grommet Mount Comp
17	630900786	Valve Solenoid Water 120V 60HZ
	630900791	Valve Solenoid Water 230V 50/60HZ
18	630201036	Brace Bulkhead
19		Water Coil Ass'y (See Figure 14)
20		Bulkhead Ass'y (See Figure 7)
21	164126000	Screw SM 8 TA TRPH 16
22	165637008	Valve Dump 120V 60HZ
	165637009	Valve Dump 230V 50/60HZ
23	630201086	Brkt Wtr Pan
24	630000788	Base Chassis (522 Series)
	630000759	Base Chassis (530 Series)
25	161763009	Tube Asy Wtr to CDR (522 Series)
	161763008	Tube Asy Wtr to CDR (530 Series)
26	164832008	Tube Water In Asy
27	164832009	Tube Water Out Asy
28	630201126	Brkt Wtr Pan Cap



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 7. BULKHEAD ASSEMBLY

Item No.	Part No.	Name
1	630900903	Clip
2	630900848	Blkhd LT
3	630900846	Blkhd Rear
4	164126000	Screw SM 8 TA TRPH 16

Item No.	Part No.	Name
5	630900934	Сар
6	630900833	Pan Water Large
7	630900892	Plug
8		Frame Evap (See Figure 8)



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 8. EVAPORATOR ASSEMBLY

Item No.	Part No.	Name
1	630900863	Frame Evap LH
2	630900781	Deflector Water
3	630201024	Gasket Frame Evap Top and Bottom
4	630250120	Tube Extension
5	630000816	Evap and Plate RH
	630000822	Evap and Plate RH (Large Cube)
6	630201030	Gasket Frame Evap R
7	630900862	Frame Evap RH

Item No.	Part No.	Name
8	630900895	Nut Hex 8-32
9	630900857	Frame Evap Bottom
10	630201029	Gasket Frame Evap L
11	630900896	Screw SM 14 HX 20
12	630900850	Blkhd RT
13	631500119	Kit Svc Evap Frame Asy
	631500137	Kit Svc Evap Frame Asy (Large Cube)



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 9. CONDENSER ASSEMBLY

Item No.	Part No.	Name
1	161870004	Cond Coil Air
2	630201109	Shroud
3	630900190	Screw SM 8 TA PAPH 12
4	630900889	Nut Well 1/4-20
5	630900309	Fan Blade
6	630900919	Brkt Wire Frmd Fan Mtr

Item No.	Part No.	Name
7	23978	Washer Sr .690 I.D.
8	165294000	Bolt MA 1/4-20 HX 32
9	630000456	Motor Asy Fan/Term 120V 60HZ
	166181011	Motor Asy Fan/Term 230V 50HZ
	630900308	Motor Asy Fan/Term 230V 60HZ
10	03612	Screw MA 8-36 HX 16



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 10. ELECTRICAL BOX ASSEMBLY

Item No.	Part No.	Name
1	630900789	Board Control Pressure Sensor
2	07578	Screw TC 8-32 TRPH 12
3	164884002	Relay Power 120V 60HZ
	40713	Relay Power 230V 50/60HZ
4	630460105	Spacer Circ Board
5	630900723	Relay Start 120V 60HZ
	630900725	Relay Start 230V 50HZ
	630900724	Relay Start 230V 60HZ
6	161838002	Block Term
7	630900905	Switch Push Btn

Dort No	Nome
Part No.	Name
630200166	Cap Strap
630900732	Capac Run 120V 60HZ
630900733	Capac Run 230V 50/60HZ
630900729	Capac Srt 120V 60HZ
630900730	Capac Srt 230V 50/60HZ
03611	Bushing Snap
630201032	Wrap Elec Box (522 Series)
630201035	Wrap Elec Box (530 Series)
630900102	Block Term (230V 50HZ)
	630900732 630900733 630900729 630900730 03611 630201032 630201035



www.cornelius.com

ILLUSTRATED PARTS LIST

Item No.	Part No.	Name
1	630900883	Cap Plg
2	630900780	Distributor Water Inner
3	630900809	O-Ring .075 I.D.
4	630900779	Distributor Water Inner Barb
5	630900777	Distributor Water Asy




FIGURE 11. WATER DISTRIBUTOR ASSEMBLY

Item No.	Part No.	Name
1	630900881	Tube Vnl Pmp to Dmp Vlv
2	630900797	Pump Water 120V 60HZ
	630900796	Pump Water 230V 50/60HZ
3	630900875	Tube Vnl Pmp to Wtr Dis
4	630900874	Tube Vnl Pmp to Out
5	166092000	Fitg Elbow




FIGURE 12. WATER PUMP ASSEMBLY

Item No.	Part No.	Name
1	630201023	Panel Fnt (522 Series)
	630201022	Panel Fnt (530 Series)
2	630900852	Cap Front Panel (522 Series)
	630900853	Cap Front Panel (530 Series)
3	630201019	Rail LT Fnt Pnl
4	630201017	Rail RT Fnt Pnl




FIGURE 13. FRONT PANEL ASSEMBLY



www.cornelius.com

ILLUSTRATED PARTS LIST




FIGURE 14. WATER COIL ASSEMBLY

Item No.	Part No.	Name
1	164980002	Valve Wtr Reg
2	08699	Fitg Union 5/8-18 By 3/8-MPT
3	22499	Cond Coil
4	164820105	Brkt Coil Wtr

Item No.	Part No.	Name
5	35987	Brkt Cond Coil
6	36039	Screw SM No. 14 HX 20
7	00214	Washer Lk .2966 I.D.
8	161168000	Screw MA 8-32 TRPH 8



www.cornelius.com

ILLUSTRATED PARTS LIST

XTREME ICE MAKER (522 AND 530 SERIES) ACCESSORIES/KITS